MIDIBox AY 3 8912 - VOLUME MENU

* Press **F4** (F3 + SHIFT) FOR THE **USER VOLUME** MENU

::.

TONE	VALUE	VELOCITY	ENVELOPE MODE
	priority 3	priority 2	priority 1
VOLUME CH. A	0 to 15	ON/OFF	ON/OFF
VOLUME CH. B	0 to 15	ON/OFF	ON/OFF
VOLUME CH. C	0 to 15	ON/OFF	ON/OFF

::.

ENVELOPE TO TONE ABC ON/OFF (ENVELOPE MODE ON)

There will be a [ENV.ON] @ Tone A or B or C on the User **Volume Control Menu** instead of the volume value if the ENVELOPE MODE is activated. If the ENVELOPE MODE is in force the Volume Value will be overwritten. For more Information about the ENVELOPE MODE see ⇒ ENVELOPE (MENU)

VELOCITY TO TONE ABC ON/OFF (VELOCITY MODE ON)

If the VELOCITY MODE is activated there will be a [VELOCITY] @ Tone A, B or C on the **User Volume Control Menu** instead of the volume value. In this case the Volume Value will be overwritten by the VELOCITY Value. Note: if VELOCITY + ENVELOPE Mode is activated the ENVELOPE MODE is in effect.

Manual Volume Control

See ⇒ midibox_ay_3_8912_mixer]

-.-

[18.11.2008]

From:
https://www.midibox.org/dokuwiki/ - **MIDIbox**

Permanent link:
https://www.midibox.org/dokuwiki/doku.php?id=midibox_ay_3_8912_volume&rev=1227017021

Last update: **2008/11/18 14:03**