# MIDIBox AY 3 8912 - VOLUME MENU

* Press **F4** (F3 + SHIFT) FOR THE **USER VOLUME** MENU

::.

| TONE | VALUE | CC 7,8 + 9 VALUE | VELOCITY | ENVELOPE MODE |
|---|---|---|---|---|
| | priority 3 | priority 3 | priority 2 | priority 1 |
| VOLUME CH. A | 0 to 15 | 0 to 127 ⇒ coversation to 0-15 | ON/OFF | ON/OFF |
| VOLUME CH. B | 0 to 15 | 0 to 127 ⇒ coversation to 0-15 | ON/OFF | ON/OFF |
| VOLUME CH. C | 0 to 15 | 0 to 127 ⇒ coversation to 0-15 | ON/OFF | ON/OFF |

::.

### ENVELOPE TO TONE ABC ON/OFF (ENVELOPE MODE ON)

There will be a [ENV.ON] @ Tone A or B or C on the User **Volume Control Menu** instead of the volume value if the ENVELOPE MODE is activated. If the ENVELOPE MODE is in force the Volume Value will be overwritten. For more Information about the ENVELOPE MODE see ⇒ ENVELOPE (MENU)

### VELOCITY TO TONE ABC ON/OFF (VELOCITY MODE ON)

If the VELOCITY MODE is activated there will be a [VELOCITY] @ Tone A, B or C on the **User Volume Control Menu** instead of the volume value. In this case the Volume Value will be overwritten by the VELOCITY Value. Note: if VELOCITY + ENVELOPE Mode is activated the ENVELOPE MODE is in effect.

### MANUAL VOLUME CONTROL

See ⇒ midibox_ay_3_8912_mixer

-.-

[18.11.2008]

From:
https://www.midibox.org/dokuwiki/ - **MIDIbox**

Permanent link:
**https://www.midibox.org/dokuwiki/doku.php?id=midibox_ay_3_8912_volume&rev=1227017265**

Last update: **2008/11/18 14:07**