

The opposite of stable; it is unstable. Usually it is used in electronics to describe a particular circuit or part of a circuit. In an astable circuit, the output continually switches between the high and low states without any intervention from the user, producing a square wave. An astable has no stable state; hence the name astable.

From:

<http://www.midibox.org/dokuwiki/> - **MIDIbox**

Permanent link:

<http://www.midibox.org/dokuwiki/doku.php?id=astable&rev=1160904901>

Last update: **2007/11/17 18:04**

