


MBHP Core8 Module

The **MBHP Core Module** is the heart and brain of every **MIDIbox**. It holds the **PIC microcontroller** which runs **MIOS** and your **MIDIbox application**. It handles MIDI communication, it drives an LCD (or two), and it connects to all the other modules.

Main part of this module is the PIC18F452, a microcontroller manufactured by Microchip. It is clocked at 40 MHz (externaly with a 10 MHz crystal) and offers enough performance to handle analog and digital modules with latencies below 1ms.



The PIC is a **“system on chip” (SoC)**, this means, it contains not only a CPU, but also an **integrated 32k flash program memory, 1536 bytes data memory, 256 bytes data EEPROM, and a lot of usefull peripherals like AD-converter and UART (for MIDI)**. The low prices and worldwide availability for hobbyists makes it a good choice.

In distance to other (more modern) microcontrollers, the PIC is easy to program, requires no external memories, is almost non-destroyable and comes in a handy DIP package, so that also electronic beginners can work with this chip without the danger of damaging small SMD pins within some seconds with their soldering iron.

Parts

- [Core Board Parts List](#)

PIC Microcontrollers

The Core Module can be equipped with following microcontrollers:

- [PIC18F4620](#) required for *MIDIbox SEQ V3*, possible future default
- [PIC18F4685](#) required for *MIDIbox SID V2* due to the CAN peripheral

Multiple Cores

There are different possibilities to have multiple Cores.

- [MIDIbox Link](#) ^{uCApps} *Linking multiple Cores via MIDI (a special configured MIDI forwarding pipe)*
- [MBNet](#) ^{uCApps} *The new MIDIbox Network utilizing the [CAN](#) (Controller Area Network) Interface on the brandnew [PIC18F4685](#) microcontrollers*

From:
<http://www.midibox.org/dokuwiki/> - **MIDIbox**



Permanent link:

http://www.midibox.org/dokuwiki/doku.php?id=core_module&rev=1470233911

Last update: **2016/08/03 14:18**