


LPC17 Core 32 Board parts list



[Official Ucapps Page](#)

Parts List

Description	Type	Qty	Reichelt Ref	Mouser Ref	Digikey Ref
74HC595	IC	1	74HC 595		
74HCT541	IC	1	74HCT 541		
7805	VR	1	uA 7805		
LF33	VR	1	LF 33 CV		
Rectifier	Rect	1	B80C800RUND		
6N138	Optocoupler	2	6N 138		
1N4148	Diode	3	1N 4148		
BC337	Transistor	1	BC 337-16		
10 kΩ	Resistor	1	1/4W 10k		
4.7 kΩ	Resistor	2	1/4W 4.7k		
2.2 kΩ	Resistor	4	1/4W 2.2k		
1 kΩ	Resistor	4	1/4W 1.0k		
220 Ω	Resistor	2	1/4W 220		
47 Ω	Resistor	4	1/4W 47		
ResNet 4*10 kΩ	Resistor	1	SIL 5-4 10K		
ResNet 4*1 kΩ	Resistor	1	SIL 5-4 1,0K		
100 nF	Capa Ceram	4	Z5U-2,5 100n		
330 nF	Capa Ceram	1	MKS-2 330n		
47 μF	Capa Elec	1	rad 47/25		
100 μF	Capa Elec	1	rad 100/16		
2200 μF	Capa Elec	1	rad 2.200/16		
TrimmPot 10 k	Pot	2	PT 6-L 10K		

Description	Type	Qty	Reichelt Ref	Mouser Ref	Digikey Ref
Optocoupler Sockets	Socket	2	GS 8		
74HC595 Socket	Socket	1	GS 16		
74HCT541 Socket	Socket	1	GS 20		
MIDI sockets	Socket	4	MABP 5S		
2×5 DIL Sockets	Socket	7	PFL 10		
2×8 DIL Sockets	Socket	2	PFL 16		
1-row sockets (opt)	Socket	5	BL 1X20G 2,54		
2×10 DIL Header	PinHeader	1	WSL 20G		
2×8 DIL Headers	PinHeader	2	WSL 16G		
2×5 DIL Headers	PinHeader	7	WSL 10G		
1-row SIL Headers	PinHeader	3	SL 1X40G 2,54		
2-row SIL Headers	PinHeader	2	SL 2X10G 2,54		

From:

<http://www.midibox.org/dokuwiki/> - **MIDIbox**

Permanent link:

http://www.midibox.org/dokuwiki/doku.php?id=lpc17_core_board_parts_list&rev=1465248417

Last update: **2016/06/06 22:26**

