

MIDIBox AY 3 8912 MIDI to Hz Chart

fT = Tone frequency [Frequency (Hz)]

fCLOCK = input clock frequency [2Mhz Crystal = 2.000.000 Hz]

TP = Decimal equivalent of the Tone Period bit 0 to 11 (Coarse Tune + Fine Tune)

MIDI Note 0: TP = (2.000.000Hz) / (16x(8,1757989156 Hz))

MIDI Note (DEC)	Note	Frequency (Hz) @2Mhz AY-3-8912	ABC Tone Period BIT0 to BIT11 (DEC)	AY 3 8912 ABC Tone Period :: BIT0 to BIT11 (BIN)	COARSE TUNE REG HEX	FINE TUNE REG HEX
INVALID 4 BIT COARSE TUNE (HEX FF-10)						
0	C	8.1757989156	15289	0011 1011 1011 1001	3B	B9
1	Db	8.6619572180	14431	0011 1000 0101 1111	38	5F
2	D	9.1770239974	13621	0011 0101 0011 0101	35	35
3	Eb	9.7227182413	12856	0011 0010 0011 1000	32	38
4	E	10.3008611535	12135	0010 1111 0110 0111	2F	67
5	F	10.9133822323	11454	0010 1100 1011 1110	2C	BE
6	Gb	11.5623257097	10811	0010 1010 0011 1011	2A	3B
7	G	12.2498573744	10204	0010 0111 1101 1100	27	DC
8	Ab	12.9782717994	9631	0010 0101 1001 1111	25	9F
9	A	13.7500000000	9091	0010 0011 1000 0011	23	83
10	Bb	14.5676175474	8581	0010 0001 1000 0101	21	85
11	B	15.4338531643	8099	0001 1111 1010 0011	1F	A3
12	C	16.3515978313	7645	0001 1101 1101 1101	1D	DD
13	Db	17.3239144361	7215	0001 1100 0010 1111	1C	2F
14	D	18.3540479948	6810	0001 1010 1001 1010	1A	9A
15	Eb	19.4454364826	6428	0001 1001 0001 1100	19	1C
16	E	20.6017223071	6067	0001 0111 1011 0011	17	B3
17	F	21.8267644646	5727	0001 0110 0101 1111	16	5F

MIDI Note (DEC)	Note	Frequency (Hz) @2Mhz AY-3-8912	ABC Tone Period BIT0 to BIT11 (DEC)	AY 3 8912 ABC Tone Period :: BIT0 to BIT11 (BIN)	COARSE TUNE REG HEX	FINE TUNE REG HEX
18	Gb	23.1246514195	5405	0001 0101 0001 1101	15	1D
19	G	24.4997147489	5102	0001 0011 1110 1110	13	EE
20	Ab	25.9565435987	4816	0001 0010 1101 0000	12	D0
21	A	27.5000000000	4545	0001 0001 1100 0001	11	C1
22	Bb	29.1352350949	4290	0001 0000 1100 0010	10	C2
VALID 4 BIT COARSE TUNE (HEX 0F-00)						
23	B	30.8677063285	4050	0000 1111 1101 0010	0F	D2
24	C1	32.7031956626	3822	0000 1110 1110 1110	0E	EE
25	Db	34.6478288721	3608	0000 1110 0001 1000	0E	18
26	D	36.7080959897	3405	0000 1101 0100 1101	0D	4D
27	Eb	38.8908729653	3214	0000 1100 1000 1110	0C	8E
28	E	41.2034446141	3034	0000 1011 1101 1010	0B	DA
29	F	43.6535289291	2863	0000 1011 0010 1111	0B	2F
30	Gb	46.2493028390	2703	0000 1010 1000 1111	0A	8F
31	G	48.9994294977	2551	0000 1001 1111 0111	09	F7
32	Ab	51.9130871975	2408	0000 1001 0110 1000	09	68
33	A	55.0000000000	2273	0000 1000 1110 0001	08	E1
34	Bb	58.2704701898	2145	0000 1000 0110 0001	08	61
35	B	61.7354126570	2025	0000 0111 1110 1001	07	E9
36	C	65.4063913251	1911	0000 0111 0111 0111	07	77
37	Db	69.2956577442	1804	0000 0111 0000 1100	07	0C
38	D	73.4161919794	1703	0000 0110 1010 0111	06	A7

MIDI Note (DEC)	Note	Frequency (Hz) @2Mhz AY-3-8912	ABC Tone Period BIT0 to BIT11 (DEC)	AY 3 8912 ABC Tone Period :: BIT0 to BIT11 (BIN)	COARSE TUNE REG HEX	FINE TUNE REG HEX
39	Eb	77.7817459305	1607	0000 0110 0100 0111	06	47
40	E	82.4068892282	1517	0000 0101 1110 1101	05	ED
41	F	87.3070578583	1432	0000 0101 1001 1000	05	98
42	Gb	92.4986056779	1351	0000 0101 0100 0111	05	47
43	G	97.9988589954	1276	0000 0100 1111 1100	04	FC
44	Ab	103.8261743950	1204	0000 0100 1011 0100	04	B4
45	A	110.0000000000	1136	0000 0100 0111 0000	04	70
46	Bb	116.5409403795	1073	0000 0100 0011 0001	04	31
47	B	123.4708253140	1012	0000 0011 1111 0100	03	F4
48	C	130.8127826503	956	0000 0011 1011 1100	03	BC
49	Db	138.5913154884	902	0000 0011 1000 0110	03	86
50	D	146.8323839587	851	0000 0011 0101 0011	03	53
E	Eb	155.5634918610	804	0000 0011 0010 0100	03	24
52	E	164.8137784564	758	0000 0010 1111 0110	02	F6
53	F	174.6141157165	716	0000 0010 1100 1100	02	CC
54	Gb	184.9972113558	676	0000 0010 1010 0100	02	A4
55	G	195.9977179909	638	0000 0010 0111 1110	02	7E
56	Ab	207.6523487900	602	0000 0010 0101 1010	02	5A
57	A	220.0000000000	568	0000 0010 0011 1000	02	38
58	Bb	233.0818807590	536	0000 0010 0001 1000	02	18
59	B	246.9416506281	506	0000 0001 1111 1010	01	FA
60	C1	261.6255653006	478	0000 0001 1101 1110	01	DE
61	Db	277.1826309769	451	0000 0001 1100 0011	01	C3

MIDI Note (DEC)	Note	Frequency (Hz) @2Mhz AY-3-8912	ABC Tone Period BIT0 to BIT11 (DEC)	AY 3 8912 ABC Tone Period :: BIT0 to BIT11 (BIN)	COARSE TUNE REG HEX	FINE TUNE REG HEX
62	D	293.6647679174	426	0000 0001 1010 1010	01	AA
63	Eb	311.1269837221	402	0000 0001 1001 0010	01	92
64	E	329.6275569129	379	0000 0001 0111 1011	01	7B
65	F	349.2282314330	358	0000 0001 0110 0110	01	66
66	Gb	369.9944227116	338	0000 0001 0101 0010	01	52
67	G	391.9954359817	319	0000 0001 0011 1111	01	3F
68	Ab	415.3046975799	301	0000 0001 0010 1101	01	2D
69	A	440.0000000000	284	0000 0001 0001 1100	01	1C
70	Bb	466.1637615181	268	0000 0001 0000 1100	01	0C
71	B	493.8833012561	253	0000 0000 1111 1101	00	FD
72	C2	523.2511306012	239	1110 1111	00	EF
73	Db	554.3652619537	225	1110 0001	00	E1
74	D	587.3295358348	213	1101 0101	00	D5
75	Eb	622.2539674442	201	1100 1001	00	C9
76	E	659.2551138257	190	1011 1110	00	BE
77	F	698.4564628660	179	1011 0011	00	B3
78	Gb	739.9888454233	169	1010 1001	00	A9
79	G	783.9908719635	159	1001 1111	00	9F
80	Ab	830.6093951599	150	1001 0110	00	96
81	A	880.0000000000	142	1000 1110	00	8E
82	Bb	932.3275230362	134	1000 0110	00	86
83	B	987.7666025122	127	0111 1111	00	7F
84	C3	1045.0226120240	120	0111 1000	00	78
85	Db	1108.7305239075	113	0111 0001	00	71
86	D	1174.6590716696	106	0110 1010	00	6A
87	Eb	1244.5079348883	100	0110 0100	00	64
88	E	1318.5102276515	95	0101 1111	00	5F
89	F	1396.9129257320	89	0101 1001	00	59
90	Gb	1479.9776908465	84	0101 0100	00	54
91	G	1567.9817439270	80	0101 0000	00	50
92	Ab	1661.2187903198	75	0100 1011	00	4B
93	A	1760.0000000000	71	0100 0111	00	47

MIDI Note (DEC)	Note	Frequency (Hz) @2Mhz AY-3-8912	ABC Tone Period BIT0 to BIT11 (DEC)	AY 3 8912 ABC Tone Period :: BIT0 to BIT11 (BIN)	COARSE TUNE REG HEX	FINE TUNE REG HEX
94	Bb	1864.6550460724	67	0100 0011	00	43
95	B	1975.5332050245	63	0011 1111	00	3F
96	C4	2093.0045224048	60	0011 1100	00	3C
97	Db	2217.4610478150	56	0011 1000	00	38
98	D	2349.3181433393	53	0011 0101	00	35
99	Eb	2489.0158697766	50	0011 0010	00	32
100	E	2637.0204553030	47	0010 1111	00	2F
101	F	2793.8258514640	45	0010 1101	00	2D
102	Gb	2959.9553816931	42	0010 1010	00	2A
103	G	3135.9634878540	40	0010 1000	00	28
104	Ab	3322.4375806396	38	0010 0110	00	26
105	A	3520.0000000000	36	0010 0100	00	24
106	Bb	3729.3100921447	34	0010 0010	00	22
107	B	3951.0664100490	32	0010 0000	00	20
108	C	4186.0090448096	30	0001 1110	00	1E
109	Db	4434.9220956300	28	0001 1100	00	1C
110	D	4698.6362866785	27	0001 1011	00	1B
111	Eb	4978.0317395533	25	0001 1001	00	19
112	E	5274.0409106059	24	0001 1000	00	18
113	F	5587.6517029281	22	0001 0110	00	16
114	Gb	5919.9107633862	21	0001 0101	00	15
115	G	6271.9269757080	20	0001 0100	00	14
116	Ab	6644.8751612791	19	0001 0011	00	13
117	A	7040.0000000000	18	0001 0010	00	12
118	Bb	7458.6201842894	17	0001 0001	00	11
119	B	7902.1328200980	16	0001 0000	00	10
120	C	8372.0180896192	15	1111	00	0F
121	Db	8869.8441912599	14	1110	00	0E
122	D	9397.2725733570	13	1101	00	0D
123	Eb	9956.0634791066	13	1101	00	0D
124	E	10548.0818212118	12	1100	00	0C
125	F	11175.3034058561	11	1011	00	0B
126	Gb	11839.8215267723	11	1011	00	0B
127	G	12543.8539514160	10	1010	00	0A

From:

<http://www.midibox.org/dokuwiki/> - **MIDIbox**

Permanent link:

http://www.midibox.org/dokuwiki/doku.php?id=mb_ay_3_8912_-_midi_to_hz_chart&rev=1230206977Last update: **2008/12/25 12:09**