Motorfader Module

MF Module is used to control up to 8 motorized faders.

- MF Module [uCApps]

The MF module connects to J7 on the core module, and also connects to the motors on the faders. The faders' positions (analog values) are read directly by the CORE module.

The MF module is used by the MIDIbox LC application.

From:
http://www.midibox.org/dokuwiki/ - **MIDIbox**

Permanent link:
http://www.midibox.org/dokuwiki/doku.php?id=mf_ng_module&rev=1468254175

Last update: **2016/07/11 17:22**