

MB SEQ functions - quick reference

Detailed info for options and functions is available at

http://www.ucapps.de/midibox_seq_manual_m.html

#	Function	Description / Options
Dedicated button functions (these can vary depending on panel design and MBSEQ_HW.V4 file)		
1	Pattern 1,2,3,4	Select pattern/track group - G1, G2, G3, G4
2	Track 1,2,3,4	Select track within track group - T1, T2, T3, T4 (16 tracks are available in total)
3	Trigger layer A,B,C	Select trigger layer A or B or C. Holding C opens trigger layer selection menu and allows to select others Gate Acc Roll Glide Skip R.G(random gate) R.V(random value) No FX
4	Parameter layer A,B,C	Select parameter layer A and B. C switches between C & D or if <i>Pressed&Hold</i> opens parameter layer selection menu and allows to select others. Four parameter layers available by default, but CC, Pitch, Prob, Delay can be added via trigger selection menu (?) 
5	Step View	View and select steps if more than 16 are used 1..16 17..32 ...etc
6	Pattern	Select/load pattern/track group G1, G2, G3, G4 from SD memory location
7	Song	Select song parameters Song # Position Action(Stop; x1..x16; Jump Pos; Jump Song; Mixer; Tempo; Mutes) Select patterns G1,G2,G3,G4
8	Edit	Enter edit mode to edit parameter layer step values and set trigger layer steps
9	Mute	Quickly mute/unmute tracks 1...16
10	Solo	Solo current track
11	←/→ (Left/Right)	Move cursor position (Left has limited usage)
4	a b	

From:

<http://www.midibox.org/dokuwiki/> - **MIDIbox**

Permanent link:

http://www.midibox.org/dokuwiki/doku.php?id=midibox_seq_quick_reference&rev=1273337422 

Last update: **2010/05/08 17:50**