

# DIN Board parts list



[Official Ucapps Page](#)

## Parts List

Description	Type	Quantity	Reichelt Ref	Mouser Ref	Digikey Ref
74HC165	IC	4	74HC 165	595-SN74HC165N	
ResNet 10kΩ	Resistor	4	SIL 6-5 10K	652-4116R-1LF-10k	
100nf	Capa Ceram	4	Z5U-2,5 100n	80-C412C104K5R	
Socket DIP16	Socket	4	GS 16	653-XR2A-1611-N	
Sockets DIL 2x5	Socket	2	WSL 10G		
DIL	Pinheader	1	SL 2X40G 2,54		

From:  
<https://www.midibox.org/dokuwiki/> - **MIDIbox**

Permanent link:  
[https://www.midibox.org/dokuwiki/doku.php?id=din\\_board\\_parts\\_list&rev=1465306525](https://www.midibox.org/dokuwiki/doku.php?id=din_board_parts_list&rev=1465306525)

Last update: **2016/06/07 13:35**

