

# DOUT Board parts list



[Official Ucapps Page](#)

## Parts List

| Description     | Type       | Quantity | Reichelt Ref  | Mouser Ref        | Digikey Ref |
|-----------------|------------|----------|---------------|-------------------|-------------|
| 74HC595         | IC         | 4        | 74HC 165      | 595-SN74HC595N    |             |
| ResNet 220Ω     | Resistor   | 4        | SIL 6-5 220   | 652-4116R-1LF-220 |             |
| 100nf           | Capa Ceram | 4        | Z5U-2,5 100n  | 80-C412C104K5R    |             |
| Socket DIP16    | Socket     | 4        | GS 16         | 653-XR2A-1611-N   |             |
| Sockets DIL 2x5 | Socket     | 2        | WSL 10G       |                   |             |
| DIL             | Pinheader  | 1        | SL 2X40G 2,54 | 855-M20-9982046   |             |

From:  
<https://www.midibox.org/dokuwiki/> - **MIDIbox**

Permanent link:  
[https://www.midibox.org/dokuwiki/doku.php?id=dout\\_board\\_parts\\_list&rev=1465347477](https://www.midibox.org/dokuwiki/doku.php?id=dout_board_parts_list&rev=1465347477)

Last update: **2016/06/08 00:57**

