


DOUT Board parts list



[Official Ucapps Page](#)

Parts List

| Description | Type | Quantity | Reichelt Ref | Mouser Ref | Digikey Ref |
|-----------------|------------|----------|---------------|-------------------|-------------|
| 74HC595 | IC | 4 | 74HC 595 | 595-SN74HC595N | |
| ResNet 220Ω | Resistor | 4 | SIL 6-5 220 | 652-4116R-1LF-220 | |
| 100nf | Capa Ceram | 4 | Z5U-2,5 100n | 80-C412C104K5R | |
| Socket DIP16 | Socket | 4 | GS 16 | 653-XR2A-1611-N | |
| Sockets DIL 2x5 | Socket | 2 | WSL 10G | 538-87834-1019 | |
| DIL | Pinheader | 1 | SL 2X40G 2,54 | 855-M20-9982046 | |

Datasheets

[74HC595](#)

From: <https://www.midibox.org/dokuwiki/> - **MIDIbox**

Permanent link: https://www.midibox.org/dokuwiki/doku.php?id=dout_board_parts_list&rev=1465821907

Last update: **2016/06/13 12:45**

