






R2
R32
Q1
C8
C9
R23
R36
R37
R39
R38
R17
R12
R7
C10
J8
S2 S2 S1
OUT2
OUT IN
IO8
MAIN
LED11
R10
IN3
IC2
IC5
IC10
C5
LED4
OUT3
J4
SD
SC
PD
OUT IN



GM5x5x5
build now. schem later.™
UL 94V-0
USB


GM5x5x5
build now. schem later.™
UL 94V-0
USB
S3 S2 S1 J8
jumper table
OUT2
IN2


GM5x5x5
build now, schem later
USB
IN1
OUT1
IN2
OUT2
IN3
OUT3
IN4
OUT4
IN5
OUT5
WIMA
+5V
GND
USB


YAGEO
WIMA


GM5x5x5
build now, schem later™



From:
https://www.midibox.org/dokuwiki/ - **MIDIbox**

Permanent link:
https://www.midibox.org/dokuwiki/doku.php?id=gm5x5x5_noob_guide&rev=1235474696

Last update: **2009/02/24 11:24**