


# MIDiBox AY 3 8912 - CS LED (wiring)

MIDiBox AY CS - Tone LEDs:




Tone LED Indication:

- Tone [A,B,C] On/Off
- Noise [A,B,C] ON/OFF

- Fx Option [A,B,C] ON/OFF


⋮  
⋮  
⋮

MIDIBox AY CS - Envelope LEDs:



Context:

- MIDIBox AY Envelope Control See ⇒ [midibox\\_ay\\_3\\_8912\\_envelope](#)



From:  
<https://www.midibox.org/dokuwiki/> - **MIDIbox**

Permanent link:  
[https://www.midibox.org/dokuwiki/doku.php?id=midibox\\_ay\\_cs\\_led&rev=1269866585](https://www.midibox.org/dokuwiki/doku.php?id=midibox_ay_cs_led&rev=1269866585)

Last update: **2010/03/29 12:43**

