MIDIBox AY 3 8912 - PATCH MENU

Access the **PATCH MENU** via **F1**

The Patch Menu:

LCD Menu			
LCD ROW	**Func.**	**Data**	**Memo**
1	NAME:	PATCH NAME	Edit the Patch Name here
2	NR :	0 to 127	Patch 0 = PIC internal Patch / 1 to 127 = Bankstick Patches
3	DO :	L W F	**L**oad Patch, **W**rite Patch, **F**ormat Bankstick1
4	status	(info)	

Annotation:

- Bankstick = Bankstick1 by default
- A “ **!** ” before the [Patch Name] (@LCD ROW1) indicates, that the Patch is NOT loaded yet.

LCD ROW	**EDIT**	**KEYS**
1	NAME	Use A-Z, 0-9, SPACE = “_”, after Patch Name Editing the user can delete the Patch Name via INST DEL key
2	Nr.	Use crsr ← → (+ / -)
3	Do	Use L W F
4	status	(info)

From:
https://www.midibox.org/dokuwiki/ - **MIDIbox**

Permanent link:
https://www.midibox.org/dokuwiki/doku.php?id=midibox_ay_patch_menu&rev=1258811521

Last update: **2009/11/21 13:52**