#	Function	Description
1	Pattern 1,2,3,4	Select pattern/track group (G1, G2, G3, G4)
2	Track 1,2,3,4	Select track within track group (T1, T2, T3, T4). 16 tracksa are available in total
3	Trigger layer A,B,C	Select trigger layer A and B (C switches between C & D or if Press&Hold opens trigger layer selection
		<html> This is some inline HTML</html>

adsfasdf |

From:
https://www.midibox.org/dokuwiki/ - **MIDIbox**

Permanent link:
https://www.midibox.org/dokuwiki/doku.php?id=midibox_seq_quick_reference&rev=1273331640

Last update: **2010/05/08 15:14**