

# MB SEQ functions - quick reference

#	Function	Description / Options										
<b>Dedicated button functions (these can vary depending on panel design and MBSEQ_HW.V4 file)</b>												
1	Pattern 1,2,3,4	Select pattern/track group - G1, G2, G3, G4										
2	Track 1,2,3,4	Select track within track group - T1, T2, T3, T4 (16 tracks are available in total)										
3	Trigger layer A,B,C	Select trigger layer A or B or C. Holding C opens trigger layer selection menu and allows to select others <html>	Gate	Acc	Roll		Glide	Skip		R.G(random gate)	R.V(random value)	No FX </html>
4	Parameter layer A,B,C	Select parameter layer A and B. C switches between C & D or if <i>Pressed&amp;Hold</i> opens parameter layer selection menu and allows to select others <html>	Note	Vel	Length		Roll					</html> these are default options, but CC, Pitch, Prob, Delay can be added via trigger selection menu (?) 
5	Step View	View and select steps if more than 16 are used <html>	1..16	17..32	...etc</html>							
4	a	b										

From: <https://www.midibox.org/dokuwiki/> - MIDibox

Permanent link: [https://www.midibox.org/dokuwiki/doku.php?id=midibox\\_seq\\_quick\\_reference&rev=1273335382](https://www.midibox.org/dokuwiki/doku.php?id=midibox_seq_quick_reference&rev=1273335382)

Last update: 2010/05/08 16:16

