MB SEQ functions - quick reference

Detailed info for options and functions is available at
http://www.ucapps.de/midibox_seq_manual_m.html

#	Function	Description / Options									
Dedicated button functions *(theese can vary depending on panel design and MBSEQ_HW.V4 file)*											
1	Pattern 1,2,3,4	Select pattern/track group - G1, G2, G3, G4									
2	Track 1,2,3,4	Select track within track group - T1, T2, T3, T4 (16 tracks are available in total)									
3	Trigger layer A,B,C	Select trigger layer A or B or C. Holding C opens trigger layer selection menu and allows to select others <html>	Gate	Acc	Roll	Glide	Skip	R.G(random gate)	R.V(random value)	No FX	</html>
4	Parameter layer A,B,C	Select parameter layer A and B. C switches between C & D or if *Pressed&Hold* opens parameter layer selection menu and allows to select others. Four parameter layers available by default, but CC, Pitch, Prob, Delay can be added via trigger selection menu (?) Fix Me! <html>	Note	Vel	Length	Roll	</html>				
5	Step View	View and select steps if more than 16 are used <html>	1..16	17..32	...etc</html>						
6	Pattern	Select/load pattern/track group G1, G2, G3, G4 from SD memory location									
7	Song	Select song parameters <html>	Song #	Position	Action(Stop; x1..x16; Jump Pos; Jump Song; Mixer; Tempo; Mutes)		Select patterns G1,G2,G3,G4	</html>			

4 a b

From:
https://www.midibox.org/dokuwiki/ - **MIDIbox**

Permanent link:
https://www.midibox.org/dokuwiki/doku.php?id=midibox_seq_quick_reference&rev=1273336489

Last update: **2010/05/08 16:34**