MB SEQ functions - quick reference

Detailed info for options and functions is available at
http://www.ucapps.de/midibox_seq_manual_m.html

#	Function	Description / Options										
Dedicated button functions *(theese can vary depending on panel design and MBSEQ_HW.V4 file)*												
1	Pattern 1,2,3,4	Select pattern/track group - G1, G2, G3, G4										
2	Track 1,2,3,4	Select track within track group - T1, T2, T3, T4. 16 tracks are available in total										
3	Trigger layer A,B,C	Select trigger layer A or B or C. Holding C opens trigger layer selection menu and allows to select others <html>	Gate	Acc	Roll	Glide	Skip	R.G(random gate)	R.V(random value)	No FX	</html>	
4	Parameter layer A,B,C	Select parameter layer A and B. C switches between C & D or with *Pressed&Hold* open parameter layer selection menu and allows to select others. Four parameter layers available by default, but CC, Pitch, Prob, Delay can be added via trigger selection menu *(?)* Fix Me! <html>	Note	Vel	Length	Roll	</html>					
5	Step View	View and select steps if more than 16 are used <html>	1..16	17..32	...etc</html>							
6	Pattern	Select/load pattern/track group G1, G2, G3, G4 from SD memory location										
7	Song	Select song parameters <html>	Song #	Position	Action{Stop; x1..x16; Jump Pos; Jump Song; Mixer; Tempo; Mutes}		Select patterns G1,G2,G3,G4	</html>				
8	Edit	Enter edit mode to edit parameter layer step values and set trigger layer steps										
9	Mute	Quickly mute/unmute tracks 1...16										
10	Solo	Solo current track										
11	←/→ *(Left/Right)*	Move cursor position. *Left* has limited usage										

#	Function	Description / Options										
12	+/- *(Inc/Dec)*	Same as *Jog Dial* encoder - increases/decreases the current value										
13	Exit	Quickly exit to top menu										
14	Select	*(Press&Hold)* Select steps to be controlled by *All* function. Obviously has usage in other situations as well 										
15	All	Edit all selected steps set with *Select* function										
16	Copy	Copy steps from selected # to #. Selection can be edited by *Select* function										
17	Paste	Paste copied steps starting from # step. Selection can be edited by *Select* function										
18	F1 *(Clear)*	*(Press&Hold)* Wipe selected track. Other functions can be assigned in MBSEQ_HW.V4 file										
19	F2 *(Select track)*	*(Press&Hold)* Select track. Other functions can be assigned in MBSEQ_HW.V4 file										
20	F3 *(Select parameter layer)*	*(Press&Hold)* Select parameter layer A,B,C,D...etc. Other functions can be assigned in MBSEQ_HW.V4 file										
21	F4 *(Select trigger layer)*	*(Press&Hold)* Select/assigns trigger layer 1..8. Other functions can be assigned in MBSEQ_HW.V4 file										
22	Rec	Open record menu <html>	Track #	Record{Live; Step}	Mode{Mono; Poly}	AStart{on; off}	Step #	TglGate		Port #	Chn #	</html>
23	«	Rewind. Active only in song mode										
24	Stop	Stop playback and reset position to beginning										
25	Play	Start playback of patterns/song										
26	Pause	Halt/resume playback										

#	Function	Description / Options										
27	»	Forward. Active only in song mode										
28	Metronome	Toggle metronome on/off										
29	Fast	Activate *Fast* mode for quicker value selection with encoders. Speed options for *Fast* can be changed in MBSEQ_HW.V4 file										
30	Scrub	*(Press&Hold) + Jog Wheel* dynamically change actual position										

4 a b

From:
https://www.midibox.org/dokuwiki/ - **MIDIbox**

Permanent link:
https://www.midibox.org/dokuwiki/doku.php?id=midibox_seq_quick_reference&rev=1273340762

Last update: **2010/05/08 17:46**