

SID Board parts list



[Official Ucapps Page](#)

Parts List

Description	Type	Quantity	Reichelt Ref	Mouser Ref	Digikey Ref
74HC595	IC	2	74HC 595	595-SN74HC00N	
Rectifier	Rect	1	B80C800RUND	625-B80C800G-E4	
78L12	VR	1	uA 78L12	512-LM78L12ACZ	
1 k Ω	Resistor	2	1/4W 1.0k	291-1K-RC	
10 k Ω	Resistor	1	1/4W 10k	291-10K-RC	
470 pF	Capa Ceram	1	Kerko 470p	80-C315C471G5G	
Syro 470 pF 2.5%		2	Styroflex 470p		
1 nF	Capa Ceram	2	Kerko 1,0n		
100 nF	Capa Ceram	4	Z5U-2,5 100n		
330 nF	Capa Ceram	1	MKS-2 330n		
1 μ F/16V	Capa Elec	1	rad 1/63		
10 μ F/16V	Capa Elec	2	rad 10/35		
2200 μ F/25V(!)	Capa Elec	1	rad 2.200/25		
BC547	Transistor	1	BC 547C	512-BC547BTA	
SID Sockets	Socket	1	GS 28	653-XR2A-2811-N	
74HC595 Sockets	Socket	2	GS 16	653-XR2A-1611-N	
SIL	PinHeader	1	SL 1X40G 2,54		
DIL	PinHeader	1	SL 2X40G 2,54		

From:

<https://www.midibox.org/dokuwiki/> - **MIDIbox**

Permanent link:

https://www.midibox.org/dokuwiki/doku.php?id=sid_board_parts_list&rev=1465384869

Last update: **2016/06/08 11:21**

