



**THIS DOCUMENT IS CURRENTLY UNDER CONSTRUCTION**



# MSA (Mathmatical Sound Architecture)

MSA commands are stored in the 64-Byte input buffer and are executed in the order they are received.

## MSA Controls

### Pause

000: Pause 0 ms  
001: Pause 100 ms  
002: Pause 200 ms  
003: Pause 700 ms

004: Pause 30 ms  
005: Pause 60 ms  
006: Pause 90 ms

016: Wait

### Next Sound

007: Play next sound fast  
008: Play next sound slow

014: Play next sound high  
015: Play next sound low

====

From:  
<https://www.midibox.org/dokuwiki/> - **MIDIbox**

Permanent link:  
[https://www.midibox.org/dokuwiki/doku.php?id=speakjet\\_control\\_overview&rev=1150034734](https://www.midibox.org/dokuwiki/doku.php?id=speakjet_control_overview&rev=1150034734)

Last update: **2006/10/15 09:35**

