

Jumper chooses Chip Select line:
Module1: RC2 (default), Module2: RC1
Additional Chip Selects: connect a wire
directly from middle pin to uC pin

MIDIbox Hardware Platform
MBHP_AINSER8_V1
(C) T. Klose 2013-03-26