

This page is dedicated to examining the sysex setup file Drums_init.syx which configures a blank pattern for drum mode.

Header

Instruction Header	F0	00	00	7E	47
Device Number	00				
?	02				
Pattern Number	00				

Dump Data

Layer A																	
0x00	Track 1	3E	3E	3E	3E	3F	3F	3F	3F	24	14	64	7F	3C	3C	3C	3C
0x10	Track 2	3F	3F	3F	3F	3F	3F	3F	3F	27	14	64	7F	3C	3C	3C	3C
0x20	Track 3	3F	3F	3F	3F	3F	3F	3F	3F	2A	14	64	7F	3C	3C	3C	3C
0x30	Track 4	3F	3F	3F	3F	3F	3F	3F	3F	2D	14	64	7F	3C	3C	3C	3C
Layer B																	
0x040	Track 1	7F	7F	7F	7F	7F	7F	7F	7F	25	14	64	7F	7F	7F	7F	7F
0x050	Track 2	7F	7F	7F	7F	7F	7F	7F	7F	28	14	64	7F	7F	7F	7F	7F
0x060	Track 3	7F	7F	7F	7F	7F	7F	7F	7F	2B	14	64	7F	7F	7F	7F	7F
0x070	Track 4	7F	7F	7F	7F	7F	7F	7F	7F	2E	14	64	7F	7F	7F	7F	7F
Layer C																	
0x080	Track 1	4F	4F	4F	4F	4F	4F	4F	47	26	14	64	7F	40	40	40	40
0x090	Track 2	4F	4F	4F	4F	4F	4F	4F	47	29	14	64	7F	40	40	40	40
0x0a0	Track 3	4F	4F	4F	4F	4F	4F	4F	47	2C	14	64	7F	40	40	40	40
0x0b0	Track 4	4F	4F	4F	4F	4F	4F	4F	47	2F	14	64	7F	40	40	40	40
0x0c0	Line 1	09	09	09	09	09	09	09	09	06	06	06	06	00	00	00	00
0x0d0	Line 2	00	00	00	00	0F	0F	0F	0F	04	04	04	04	02	02	02	02
0x0e0	Line 3	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00
0x0f0	Line 4	0E	0F	0F	0F	0E	0F	0F	0F	0E	0F	0F	0F	0E	0F	0F	0F
0x100	Line 1	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00
0x110	Line 2	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00
0x120	Line 3	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00
0x130	Line 4	00	00	00	00	00	00	00	00	01	00	0C	08	09	00	00	00

Footer

10 F7

Drum Mode:

Header

Instruction Header	F0	00	00	7E	47
Device Number	00				
?	02				
Pattern Number	00				

Dump Data

Layer A		Mute 1-4	Mute 5-8	Mute 9-12	Mute 13-16	Accent 1-4	Accent 5-8	Accent 9-12	Accent 13-16	Note#	Gate	Velocity	Acc Velocity	Reserved			
0x00	Track 1	3E	3E	3E	3E	3F	3F	3F	3F	24	14	64	7F	3C	3C	3C	3C
0x10	Track 2	3F	3F	3F	3F	3F	3F	3F	3F	27	14	64	7F	3C	3C	3C	3C

0x20	Track 3	3F	3F	3F	3F	3F	3F	3F	3F	3F	3F	2A	14	64	7F	3C	3C	3C	3C
0x30	Track 4	3F	3F	3F	3F	3F	3F	3F	3F	3F	3F	2D	14	64	7F	3C	3C	3C	3C
Layer B																			
0x040	Track 1	7F	7F	7F	7F	7F	7F	7F	7F	7F	7F	25	14	64	7F	7F	7F	7F	7F
0x050	Track 2	7F	7F	7F	7F	7F	7F	7F	7F	7F	7F	28	14	64	7F	7F	7F	7F	7F
0x060	Track 3	7F	7F	7F	7F	7F	7F	7F	7F	7F	7F	2B	14	64	7F	7F	7F	7F	7F
0x070	Track 4	7F	7F	7F	7F	7F	7F	7F	7F	7F	7F	2E	14	64	7F	7F	7F	7F	7F
Layer C																			
0x080	Track 1	4F	4F	4F	4F	4F	4F	4F	4F	4F	47	26	14	64	7F	40	40	40	40
0x090	Track 2	4F	4F	4F	4F	4F	4F	4F	4F	4F	47	29	14	64	7F	40	40	40	40
0x0a0	Track 3	4F	4F	4F	4F	4F	4F	4F	4F	4F	47	2C	14	64	7F	40	40	40	40
0x0b0	Track 4	4F	4F	4F	4F	4F	4F	4F	4F	4F	47	2F	14	64	7F	40	40	40	40
0x0c0	Line 1	09	09	09	09	09	09	09	09	06	06	06	06	00	00	00	00	00	00
0x0d0	Line 2	00	00	00	00	0F	0F	0F	0F	04	04	04	04	02	02	02	02	02	02
0x0e0	Line 3	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00
0x0f0	Line 4	0E	0F	0F	0F	0E	0F	0F	0F	0E	0F	0F	0F	0E	0F	0F	0F	0F	0F
0x100	Line 1	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00
0x110	Line 2	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00
0x120	Line 3	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00
0x130	Line 4	00	00	00	00	00	00	00	00	01	00	0C	08	09	00	00	00	00	00
Footer																			
10	F7																		

From:

<http://wiki.midibox.org/> - **MIDIbox**

Permanent link:

<http://wiki.midibox.org/doku.php?id=drummodesysex>Last update: **2006/10/15 10:35**