Changing DOUT pins in mbSID v2

Overview

2025/08/04 06:42

If you're like me, you'd rather change the software mapping of the output (LED) pins than wire everything according to the original schematic - which may not even be possible due to differences in the CS. This HowTo will demonstrate one of the many ways to change the mapping according to your own wiring. This HowTo is only meant to change LEDs which are connected to individual pins. With LEDs connected as a matrix this will not work.

Difficulty level:

• easy ₀₋₁₋₂₋₃.**4**.5-6-7-8-9 hard

Required actions:

- Search/manually edit
- Install other software
- Compile

Affected files [1]:

setup_*.asm

Required software:

http://www.ucapps.de/mios/dout_buttons_v1_3a.zip

Step-by-Step description

1. Finding the correct pins

- Download the dout_buttons_v1_3a application. This application lights one LED at a time and displays its SR and pin number.
- Install it on the (master) core
- Power up the core. Your dispay should now show sth. like this

Digital Out Test

SR# 1 Pin#0 0x00

• Upon pressing a button which is connected to an odd pin the program will increase number of the pin to power. Pressing the button once will display this:

Digital Out Test SR# 1 Pin#1 0x01

- Pressing a button which is connected to an even pin will decrease the number of the pin to power.
- Toggle through the pins and SRs and write down the SR# and Pin# for every LED until all of your leds have been lit.
- At this point you know have all the SR# and Pin# for all the LEDs

2. Changin the source code

- Open setup_*.asm
- Find the table called CS_MENU_DOUT_TABLE which looks like this:

CS_MENU_DOUT_TABL	.E					
;; Reg	jister and bit	SR#	Pin#		Descript	ion
DOUT_ENTRY	CS_MENU_SELECTED_SID	_FLAGS, 0	,	1,	0	;
SID1 LED (Note: P	in #0 is the D7 outpu	t of firs	t SR)			
DOUT_ENTRY	CS_MENU_SELECTED_SID	_FLAGS, 1	,	1,	1	;
SID2 LED						
DOUT_ENTRY	CS_MENU_SELECTED_SID	_FLAGS, 2	,	1,	2	;
SID3 LED						
DOUT_ENTRY	CS_MENU_SELECTED_SID	_FLAGS, 3	,	1,	3	;
SID4 LED						
DOUT_ENTRY	CS_MENU_MODE, 0,	1	, 4	;	Shift LE	Đ
DOUT_ENTRY	CS_MENU_MODE, 1,	1	, 5	;	CC LED	
DOUT_ENTRY	CS_MENU_MODE, 4,	1	, 6	;	Edit LED)
DOUT_ENTRY	CS_MENU_SELECTED_OSC	_FLAGS, 0	,	2,	0	;
OSCI LED	COMENIL OF FOTED ACC			2	-	
DOUT_ENTRY	CS_MENU_SELECTED_OSC	_FLAGS, I	,	۷,	T	;
USCZ LED				2	2	
DUUI_ENIRY	CS_MENU_SELECTED_USC	_FLAGS, 2	1	۷,	2	;
USC3 LED						
DOUT ENTRY	TMD1 0	С	. .	050	Env LED	
	TMP1, 0,	2, 2	сі с	050)
	TMP1 2	2, 2	4 ;	050	MISC LEL	, ED
DOUT_ENTRY	INFI, Z,	ζ,	; C	050	ASSIGN L	Ľυ
DOUT ENTOV	TMD1 /	2	0	050	Trianala	
	TMD1 5	з, З	1,	050		
	IIII 1 , 3 ,	, د	± ,	050	Jaw LLD	

6:42	3/5			Changing DOUT pins in mbSID
DOUT_ENTRY	TMP1, <u>6</u> ,	3,	2	; OSC Pulse LED
DOUT_ENTRY	TMP1, 7,	3,	3	; OSC Noise LED
DOUT ENTRY	TMP2, 0,	2,	6	; OSC Sync LED
DOUT_ENTRY	TMP2, 1,	2,	7	; OSC Ring LED
DOUT_ENTRY	TMP3, 0,	3,	4	; Filter 01 LED
DOUT_ENTRY	TMP3, 1,	3,	5	; Filter O2 LED
DOUT_ENTRY	TMP3, 2,	3,	6	; Filter O3 LED
DOUT_ENTRY	TMP3, 3,	3,	7	; Filter Ext LED
DOUT_ENTRY	TMP3, 4,	4,	Θ	; Filter LP LED
DOUT_ENTRY	TMP3, <mark>5</mark> ,	4,	1	; Filter BP LED
DOUT_ENTRY	TMP3, <mark>6</mark> ,	4,	2	; Filter HP LED
DOUT_ENTRY	TMP3, 7,	4,	3	; Filter 30 LED
DOUT_ENTRY	TMP2, 4,	4,	4	; ENV1 LED
DOUT_ENTRY	TMP2, 5,	4,	5	; ENV2 LED
DOUT_ENTRY	TMP2, 6,	4,	6	; ENV Ctrl LED
DOUT_ENTRY	TMP2, 7,	4,	7	; ENV Assign LED
DOUT ENTRY	TMP4, 0,	5,	Θ	; LF01 LED
DOUT_ENTRY	TMP4, 1,	5,	1	; LFO2 LED
DOUT_ENTRY	TMP4, 2,	5,	2	; LFO3 LED
DOUT_ENTRY	TMP4, <u>3</u> ,	5,	3	; LFO4 LED
DOUT_ENTRY	TMP4, 4 ,	5,	4	; LF05 LED
DOUT_ENTRY	TMP4, 5,	5,	5	; LFO6 LED
DOUT ENTRY	TMP5, 0,	5,	6	; LFO Sine LED
DOUT_ENTRY	TMP5, 1,	5,	7	; LFO Triangle LED
DOUT_ENTRY	TMP5, 2,	6,	0	; LFO Saw LED
DOUT_ENTRY	TMP5, <u>3</u> ,	6,	1	; LFO Pulse LED
DOUT_ENTRY	TMP5, 4,	6,	2	; LFO Random LED
;; additional ;; o Play LED ;; o Mode Met ;; o Mode Mat ;; o SID L LE ;; o SID R LE	LED functions whi (TMP5, 6) er LED (TMP2, 2) rix LED (TMP2, 3) D (TMP4, 6) D (TMP4, 7) tive LED (TMP5 5)	ich could be	added	:

```
;; don't remove this "end-of-table" entry!
DOUT_ENTRY_EOT
```

- All you need to change is the 4th and 5th column (SR# and Pin#)
- I usually set all SR# and Pin# to 0 before changing anything that way it's hard to miss anything and it keeps you from having doubles if you do not use of the buttons
- Go through the list you've made earlier and change the Pin# and SR# according to it for each

LED.

• If there are LEDs you don't have on your CS just comment out that line by adding ;; (two semicolons) to the beginning of that line. Like this:

;; this LED will work DOUT_ENTRY CS_MENU_MODE, 0,	1,	4 ;	Shift LED
<pre>;; this LED has been removed by commentir ;; DOUT_ENTRY CS_MENU_MODE, 0,</pre>	ng out 1,	4	; Shift LED

• Done with the LEDs

3. (Optional) Additional predefined LEDs

- If you want to use any of the predefined LEDs that are commented out by default this is how to do it.
- At the end of the CS_MENU_DOUT_TABLE you'll find this

```
;; additional LED functions which could be added:
;; o Play LED (TMP5, 6)
;; o Mode Meter LED (TMP2, 2)
;; o Mode Matrix LED (TMP2, 3)
;; o SID L LED (TMP4, 6)
;; o SID R LED (TMP4, 7)
;; o LFO Positive LED (TMP5, 5)
```

 Those LEDs are predefined but not used. To use them just add a line to the table. Let's say we want the "Play LED"

;; o Play LED (TMP5, 6)

 Remove the ;; and the parentheseses and replace the name ("Play LED") by DOUT_ENTRY giving you this:

;; DOUT_ENTRY TMP5, 6

• Now add ", " + SR# + ", " + Pin# giving you sth like this:

;; DOUT_ENTRY TMP5, 6, 4, 7

• This would already work but it's a good idea to add a comment to it so you remember what this LED does:

;; DOUT_ENTRY TMP5, 6, 4, 7 ;; Play LED - whee!

• Done with the extra LEDs

2025/08/04 06:42

4. Recompile

- Now recompile the setup_*.asmSend it to your mbSID via MIOSStudio
- You're all done!

From: http://wiki.midibox.org./ - MIDIbox

Permanent link: http://wiki.midibox.org./doku.php?id=changing_dout_pins



Last update: 2009/10/22 13:13