

Changing DIN pins in mbSID v2

Overview

If you're like me, you'd rather change the software mapping of the Input pins than wire everything according to the original schematic - which may not even be possible due to differences in the CS. This HowTo will demonstrate one of the many ways to change the mapping according to your own wiring.

Difficulty level:

- easy 0-1-2-3 **4** 5-6-7-8-9 hard

Required actions:

- Search/manually edit
- Install other software
- Compile

Affected files [1]:

- setup_*.asm

Required software:

- http://www.ucapps.de/mios/ain64_din128_dout128_v2_0.zip

Step-by-Step description

1. Finding the correct pins

- Download the ain64_din128_dout128_v2_0 application
- Install it on the (master) core
- Power up the core. Your display should now show sth. like this

```
Waiting for DIN or  
AIN event
```

- Upon pressing a button it will tell you the event number like this:

```
Received a DIN
Event:      24/1
```

- Press every button and write down the corresponding number (the 24 in the example above)
- Do the same thing for the encoders. This is a bit more tricky as an encoder movement triggers 2 events. If you move the encoder back and forth a bit you should get two events. One of which is the predecessor of the other (for instance 24 and 25)
- Write down the smaller number (this *must* be an even number)
- At this point you know how your buttons and encoders are connected

2. Translating the events to SR & Pin

- For each button event number you've written down the SR & Pin numbers are
- C-Syntax: $SR = ((event_number - 1) / 8) + 1$; $Pin = (event_number - 1) \% 8$;
- Pascal-Syntax: $SR := ((event_number - 1) \text{ DIV } 8) + 1$; $Pin := (event_number - 1) \text{ MOD } 8$;
- In plain english SR is the (event number minus 1) divided by 8 (using integer division) plus 1, and the Pin is the remainder of that division.
- Do the same thing for the smaller number of each encoder
- You should now have a pair of numbers for each encoder/button on your box

3. Changing the source code for the buttons

- Open `setup_*.asm`
- Find the table called `CS_MENU_DIN_TABLE` which looks like this:

```
CS_MENU_DIN_TABLE
;;      Function name      SR#    Pin#
DIN_ENTRY  CS_MENU_BUTTON_Dec,    1,     0    ; only valid if
rotary encoder not assigned to these pins
DIN_ENTRY  CS_MENU_BUTTON_Inc,    1,     1    ; (see
mios_tables.inc) and CS_MENU_USE_INCDEC_BUTTONS == 1
DIN_ENTRY  CS_MENU_BUTTON_Exec,    1,     2
DIN_ENTRY  CS_MENU_BUTTON_Sel1,    1,     7
DIN_ENTRY  CS_MENU_BUTTON_Sel2,    1,     6
DIN_ENTRY  CS_MENU_BUTTON_Sel3,    1,     5
DIN_ENTRY  CS_MENU_BUTTON_Sel4,    1,     4
DIN_ENTRY  CS_MENU_BUTTON_Sel5,    1,     3
DIN_ENTRY  CS_MENU_BUTTON_Sel6,    0,     0    ; define this if
CS_MENU_DISPLAYED_ITEMS > 5
DIN_ENTRY  CS_MENU_BUTTON_Sel7,    0,     0    ; define this if
CS_MENU_DISPLAYED_ITEMS > 5
DIN_ENTRY  CS_MENU_BUTTON_Sel8,    0,     0    ; define this if
```

```

CS_MENU_DISPLAYED_ITEMS > 5
  DIN_ENTRY    CS_MENU_BUTTON_Sel9,      0,    0    ; define this if
CS_MENU_DISPLAYED_ITEMS > 5
  DIN_ENTRY    CS_MENU_BUTTON_Sel10,     0,    0    ; define this if
CS_MENU_DISPLAYED_ITEMS > 5

  DIN_ENTRY    CS_MENU_BUTTON_SID1,      2,    0
  DIN_ENTRY    CS_MENU_BUTTON_SID2,      2,    1
  DIN_ENTRY    CS_MENU_BUTTON_SID3,      2,    2
  DIN_ENTRY    CS_MENU_BUTTON_SID4,      2,    3
  DIN_ENTRY    CS_MENU_BUTTON_Shift,      2,    4    ; was: link
button
  DIN_ENTRY    CS_MENU_BUTTON_CC_PageUp,  2,    5    ; combined
CC/PageUp -- CC actived together with shift button (no error)
  DIN_ENTRY    CS_MENU_BUTTON_Edit_PageDown, 2, 6    ; combined
Edit/PageDown -- Edit actived together with shift button (no error)

  DIN_ENTRY    CS_MENU_BUTTON_Osc_Sel,    4,    2
  DIN_ENTRY    CS_MENU_BUTTON_Osc_Ctrl,   4,    3
  DIN_ENTRY    CS_MENU_BUTTON_Osc_Wav,    4,    4
  DIN_ENTRY    CS_MENU_BUTTON_Osc_RS,     4,    5

  DIN_ENTRY    CS_MENU_BUTTON_LF0_Sel,    5,    2
  DIN_ENTRY    CS_MENU_BUTTON_LF0_Wav,    5,    3

  DIN_ENTRY    CS_MENU_BUTTON_Env_Sel,    7,    2
  DIN_ENTRY    CS_MENU_BUTTON_Env_Ctrl,   7,    3

  DIN_ENTRY    CS_MENU_BUTTON_Fil_Sel,    7,    4
  DIN_ENTRY    CS_MENU_BUTTON_Fil_Mod,    7,    5

  DIN_ENTRY    CS_MENU_BUTTON_M_01Ptch,   7,    6
  DIN_ENTRY    CS_MENU_BUTTON_M_02Ptch,   7,    7
  DIN_ENTRY    CS_MENU_BUTTON_M_03Ptch,   8,    0
  DIN_ENTRY    CS_MENU_BUTTON_M_01PW,     8,    1
  DIN_ENTRY    CS_MENU_BUTTON_M_02PW,     8,    2
  DIN_ENTRY    CS_MENU_BUTTON_M_03PW,     8,    3
  DIN_ENTRY    CS_MENU_BUTTON_M_Filter,    8,    4
  DIN_ENTRY    CS_MENU_BUTTON_M_E1,       8,    5
  DIN_ENTRY    CS_MENU_BUTTON_M_E2,       8,    6
  DIN_ENTRY    CS_MENU_BUTTON_M_L1,       8,    7
  DIN_ENTRY    CS_MENU_BUTTON_M_L2,       9,    0
  DIN_ENTRY    CS_MENU_BUTTON_M_L3,       9,    1
  DIN_ENTRY    CS_MENU_BUTTON_M_L4,       9,    2
  DIN_ENTRY    CS_MENU_BUTTON_M_L5,       9,    3
  DIN_ENTRY    CS_MENU_BUTTON_M_L6,       9,    4
  DIN_ENTRY    CS_MENU_BUTTON_M_Vol,      9,    5    ; (new, button
below M_Filter, you could also re-arrange the assignment if you want)

;; new for MBSID V2 (additional ***optional*** buttons)
;; don't worry, you still have full access to all functions w/o

```

```

these buttons!
    ;; note that you could also re-arrange the pin assignments if
required (e.g. if you don't like a certain button function)
    DIN_ENTRY    CS_MENU_BUTTON_M_Vol,    9,    5    ; matrix: button
below M_Filter
    DIN_ENTRY    CS_MENU_BUTTON_Play,    9,    6    ; direct access
to play function
    DIN_ENTRY    CS_MENU_BUTTON_SID_LR,    9,    7    ; direct access
to L/R toggling
    DIN_ENTRY    CS_MENU_BUTTON_M_Mode,    10,    0    ; direct access
to meter on/off function
    DIN_ENTRY    CS_MENU_BUTTON_Fil_ExtIn, 10,    1    ; direct access
to Filter ExtIn Flag
    DIN_ENTRY    CS_MENU_BUTTON_Sync,    10,    2    ; jumps to
ENS->CLK menu

    ;; don't remove this "end-of-table" entry!
    DIN_ENTRY_EOT

```

- All you need to change is the 3rd and 4th column (SR# and Pin#)
- I usually set all SR# and Pin# to 0 before changing anything - that way it's hard to miss anything and it keeps you from having doubles if you do not use of the buttons
- Go through your list of buttons and adjust the SR# and Pin# according to the numbers you've written down in the previous step
- Done with the buttons

4. Changing the source code for the encoders

- (re-)open setup_*.asm
- Find the table called MIOS_ENC_PIN_TABLE which looks like this

```

MIOS_ENC_PIN_TABLE
    ;;          SR Pin Mode
#if CS_MENU_USE_INCDEC_BUTTONS == 0
    ENC_ENTRY  1,  0,  MIOS_ENC_MODE_DETENTED2    ; menu encoder
#endif

    ;; additional CS encoders
    ;;          SR Pin Mode
    ENC_ENTRY  3,  0,  MIOS_ENC_MODE_DETENTED2    ; 0sc
delay/transpose/assign #1
    ENC_ENTRY  3,  2,  MIOS_ENC_MODE_DETENTED2    ; 0sc
attack/finetune/assign #2
    ENC_ENTRY  3,  4,  MIOS_ENC_MODE_DETENTED2    ; 0sc
decay/portamento/assign #3
    ENC_ENTRY  3,  6,  MIOS_ENC_MODE_DETENTED2    ; 0sc

```

```
sustain/release/assign #4
  ENC_ENTRY 3, 8, MIOS_ENC_MODE_DETENTED2 ; 0sc
release/pulsewidth/assign #5

  ENC_ENTRY 4, 6, MIOS_ENC_MODE_DETENTED2 ; LF0 rate
  ENC_ENTRY 5, 0, MIOS_ENC_MODE_DETENTED2 ; LF0 depth

  ENC_ENTRY 5, 4, MIOS_ENC_MODE_DETENTED2 ; Filter CutOff
  ENC_ENTRY 5, 6, MIOS_ENC_MODE_DETENTED2 ; Filter Resonance

  ENC_ENTRY 6, 0, MIOS_ENC_MODE_DETENTED2 ; Env depth/assign #1
  ENC_ENTRY 6, 2, MIOS_ENC_MODE_DETENTED2 ; Env attack/assign
#2
  ENC_ENTRY 6, 4, MIOS_ENC_MODE_DETENTED2 ; Env decay/assign #3
  ENC_ENTRY 6, 6, MIOS_ENC_MODE_DETENTED2 ; Env sustain/assign
#4
  ENC_ENTRY 7, 0, MIOS_ENC_MODE_DETENTED2 ; Env release/assign
#5

;; don't remove this "end-of-table" entry!
ENC_EOT
```

- This time change columns 2 and 3 (SR and Pin) like before
- Done with the encoders

5. Recompile

- * Now recompile the setup_*.asm
- * Send it to your mbSID via MIOSSstudio
- * You're all done!

From:
<https://www.midibox.org/dokuwiki/> - **MIDIbox**

Permanent link:
https://www.midibox.org/dokuwiki/doku.php?id=changing_din_pins&rev=1205165114

Last update: **2009/10/22 13:14**

