

This page will contain the information about the combined lcd/button matrix

right now I'm using a modified version of the sm_simple C example but this code will be rewritten to make it more coherent

modifications to scan matrix example: in main.c:

```
...
//second shiftregister drives the leds
#define LEDOUT 1
...
void LM_SetRow(){
    MIOS_DOUT_SRSet(LEDOUT,ledtest[sm_col]);
}

///////////////////////////////
/
// This function is called by MIOS before the shift register are loaded
///////////////////////////////
/
void SR_Service_Prep(void) __wparam
{
    // call the Scan Matrix Driver
    SM_Prepare();
    // call the Led Matrix Driver
    LM_SetRow();
}
...
```

in sm_simple.asm:

```
...
global _sm_button_column
global _sm_button_row
global _sm_button_value
global _sm_col

;; import labels
extern _SM_NotifyToggle

; =====

accessram udata ; (no access ram required, these variables can
be located anywhere)

_sm_button_column res 1 ; exported to C, therefore an "_" has been
added
_sm_button_row res 1
_sm_button_value res 1
```

```
_sm_col           res 1

...
SM_PrepCol
;; select next DOUT register

;; (current column + 1) & 0x07
SET_BSR    sm_selected_column
incf      sm_selected_column, W, BANKED      ; (* see note below)
andlw      0x07
;_sm_col is used by LM_SetRow()
movwf      _sm_col
call      MIOS_HLP_GetBitANDMask    ; (inverted 1 of 8 code)
...
```

and finally in sm_simple.h:

```
...
extern unsigned char sm_button_value;
extern unsigned char sm_col;
...
```

From:

<http://www.midibox.org/dokuwiki/> - **MIDIbox**

Permanent link:

http://www.midibox.org/dokuwiki/doku.php?id=dseq32_matrix&rev=1152138061

Last update: **2006/10/15 09:35**

