


MB SEQ functions - quick reference


Detailed info for options and functions is available at

http://www.ucapps.de/midibox_seq_manual_m.html

Print-friendly (on two A4 sheets) xls version available here [mbseq_prn_.zip](#)

#	Function	Description / Options												
Dedicated button functions (these can vary depending on panel design and MBSEQ_HW.V4 file)														
1	Pattern 1,2,3,4	Select pattern/track group - G1, G2, G3, G4												
2	Track 1,2,3,4	Select track within track group - T1, T2, T3, T4. 16 tracks are available in total												
3	Trigger layer A,B,C	Select trigger layer A or B or C. Holding C opens trigger layer selection menu and allows to select others <html>	Gate	Acc	Roll	Glide	Skip	R.G(random gate)	R.V(random value)	No FX	</html>			
4	Parameter layer A,B,C	Select parameter layer A and B. C switches between C & D or with <i>Press&Hold</i> open parameter layer selection menu and to select others. Four parameter layers available by default, but CC, Pitch, Prob, Delay can be added via <u>trigger selection menu (?)</u>  Fix Me! <html>	Note	Vel	Length	Roll	</html>							
5	Step View	View and select steps if more than 16 are used <html>	1..16	17..32	...etc</html>									
6	Pattern	Select/load pattern/track group G1, G2, G3, G4 from SD memory location												
7	Song	Select song parameters <html>	Song #	Position	Action{Stop; x1...x16; Jump Pos; Jump Song; Mixer; Tempo; Mutes}	Select patterns: G1,G2,G3,G4	</html>							
8	Edit	Enter edit mode to edit parameter layer step values and set trigger layer steps												
9	Mute	Quickly mute/unmute tracks 1...16												
10	Solo	Solo current track												
11	←/→ (Left/Right)	Move cursor position. <i>Left</i> has limited usage												
12	+/- (Inc/Dec)	Same as <i>Jog Dial</i> encoder - increases/decreases the current value												
13	Exit	Quickly exit to top (Session) menu. <html>	(return to previous menu)	Mute Tracks	Open	Save	Save as	New	Info	</html>				

#	Function	Description / Options												
14	Select	(Press&Hold) Select steps to be controlled by <i>All</i> function. <i>Select</i> brings additional options in several other menus as well												
15	All	Edit all selected steps set with <i>Select</i> function												
16	Copy	Copy steps from selected # to #. Step # can be edited by <i>Select</i> function												
17	Paste	Paste copied steps starting from # step. Step # can be edited by <i>Select</i> function												
18	F1 (Clear)	(Press&Hold) Wipe selected track. Other functions can be assigned in MBSEQ_HW.V4 file												
19	F2 (Select track)	(Press&Hold) Select track. Other functions can be assigned in MBSEQ_HW.V4 file												
20	F3 (Select parameter layer)	(Press&Hold) Select parameter layer A,B,C,D...etc. Other functions can be assigned in MBSEQ_HW.V4 file												
21	F4 (Select trigger layer)	(Press&Hold) Select/assign trigger layer 1..8. Other functions can be assigned in MBSEQ_HW.V4 file												
22	Rec	Open record menu <html>	Track #	Record{Live; Step}	Mode{Mono; Poly}	AStart{on; off}	Step #	TglGate		Port #	Chn #	</html>		
23	«	Rewind. Active only in song mode												
24	Stop	Stop playback and reset position to beginning												
25	Play	Start playback of patterns/song												
26	Pause	Halt/resume playback												
27	»	Forward. Active only in song mode												
28	Metronome	Toggle metronome on/off												
29	Fast	Activate <i>Fast</i> mode for quicker value selection with encoders. Speed options for <i>Fast</i> can be changed in MBSEQ_HW.V4 file												
30	Scrub	(Press&Hold) + <i>Jog Wheel</i> dynamically change actual position												
Menu functions														
31	Menu+Scrub	Toggle loop mode on/off												
32	Menu+Metronome	External restart used to synchronize playback starting from next step												

#	Function	Description / Options												
33	Menu+GP1 (Mixer)	Open mixer view for 16 tracks. 12 pages can be switched with +/- . An additional options available with <i>Select</i> button <i>More details?</i> 	Midi port	Midi channel	Prog change	Volume	Panorama	Reverb	Chorus	CC1	CC2	CC3	CC4	</html>
34	Menu+GP2 (Event)	Open track setup editor <html>	Track #	Type{Note; Chord; CC; Drum}	Step #	ParL #	TrgL #	Port #	Chn #	Edit Name	</html>			
35	Menu+GP3 (Mode)	Open track mode editor <html>	Track #	Track on/off	Normal, Transpose, Arpeggiator	</html> <html>								

Hold{on; off} | Sort{on; off} | Restart{on; off} | Scale{on; off} | Sustain{on; off} | </html>

[illegible]

To do:

- check descriptions and options for all functions in this quick reference
- fix/complement all “fixme” issues
- add *highlight* and *fontcolor* [<http://www.dokuwiki.org/plugin:fontcolor>] plugins so that font/background color of the options can be changed

From: <http://www.midibox.org/dokuwiki/> - **MIDIbox**

Permanent link:
http://www.midibox.org/dokuwiki/doku.php?id=midibox_seq_quick_reference

Last update: **2010/05/18 16:45**



