

MSQ-CC-LRE

MotionSeQuencer for ControlChanges for 2xLRE8x2 Boards

Synth-Patch-Editor & Motion-Sequencer 4 ControlChange (= CC-Automation)



Video

Introduction

Controls and automate a Nord Drum2 (Drum-Synth) [NORD DRUM 2](#)

It acts as:

- **Midi Merger** NTE,CLK,PC merge with CC... - **Patch Manager** it replaces the Synths internal Patch Storage, each PC Number from your Sequencer is added by the BANK CC (CC 32), where each Nr is ADD 128 PC Numbers more...
- **Motion Sequencer** Record your Controller Movements in a Sequence in 32th Resultion @ maximal 256 Steps length

Features

- **Remote your Synths** by: 8x Midichannels with up to 32x Control Change (CC)
- **Save the Patches** and dump it to Synth
- **Load hundrets of Patches** via received Program Change + the Bank-CC (CC32)
- **Save Patches** via CC24 + CC value 0-127... when sending before a BankCC32 you can expand that to 128×128 patches
- **Record CC-Motion-Sequences - PLAY Motions-Sequences** up to 256 steps @ 32th rate -
- VELOCITY MORPH** Add Velocity-Ammount to CCs
- **MERGE** incoming Midi-Notes/Clock/Pitchbend with Automated CCs
- **Set Sequencer Beatstructure** - how to interpret Clock-ticks (4/4, 5/4, 6/4, 7/4...) - CC23
- **Global Page:** for example you use 8 simular Drum-Voices, with the Global you have 8 channel strips with dedicated Controlls, for example:
8xVolume, 8xTone/Noise-Mix, 8xDistortion, 8xClick
if you have one Synth over 2xMSQ_CC_LRE Tracks(booth set to MidiChannel 0, to get 64CCs instead of 32), then the Global Page: have the ability to show/edit a parameter from Track1Voice on Track1Global, and from Track2Voice on Track2Global... it depends how you set the Midichannel in the Systemsettings (which are hardcodet but via Mapping Array changeable)
- for one multipart-synth, MSQ_CC_LRE do all the Preset Store, and Automations, so it is one Unit > to use the Unit in a other way would make all the Patches (128×128 patches) useless, so once done, its bound to it, load all with Programchange! minimal is better here, there will be other **MSQs** outthere see [MSQ-CC-BCR](#)

Hardware Requirements

External Requirement:(for example)

- Melody/Clock Source with ProgramChange-Output: [midibox_seq_v4l](#) oops that dont do PC...
- Melody/Clock Destination: NordDrum 2

Midibox:

- [core32](#)
- [1xMidi IO](#) connect 1 midicontroller and 1 Note/Clock-Source/Destination
- SD-Card, formatted with FAT32, and the file "bcr1.syx" on it
- Soldering Iron, Wires, PCB....
- USB Power Supply... I tried to use the Midi-BUS-Power from BCR2000 but it is too weak!
- 2x LRE 8x2 [mb-lre8x2cs_pcb](#)
- 3 extra Encoders and Ledrings (to controll the unit) + Pushfunction inclusive Button LED
- 8 Momentary Buttons without LED

- 1 Momentary Button with LED
- 1x DINX4
- 1x DOUTX4

Setting

Cabeling

MidilO PortB Out >> Synth Midi IN
MidilO PortB In >> Clock+Notes

Frontpanels

Stickers

LCD

it would be possible to add 16 OLEDs but... but i dont have the money for that right now....

MBHP

Software

Firmware

V1. from 9.05.2018 [msq_cc_lre_v0.norddrum2.zip](#)

hardcodet for a NordDrum2 - but change-able in Mapping via a Array in Sourcecode:

this is the mapping which says wich of the 32 internal CCs are one of the outhernal CCs (0-127):

```
// 4 CC Route Mode = 0; // In Synthesizer
const u8 CC_Map0[32] = { // CC_Map0 [Part] [Internal CC Nr] = value of external CC =>
// CC_Map0 [MidiChannel] [Remote/Source] = Value of Synth/Destination
// 1st Row Horizontal // 2nd Row Horizontal // 3rd Row Horizontal // 4th Row Horizontal
// CC-on-LRE: 0 1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24 25 26 27 28 29 30 31
{ 57, 56, 54, 23, 26, 25, 10, 7, 25, 17, 14, 16, 18, 19, 20, 21, 46, 52, 53, 47, 48, 54, 55, 254, 50, 51, 49, 38, 58, 255, 255, 255, // Nord Drum 2 Voice 1 MultiCh 7
{ 57, 56, 54, 23, 26, 25, 10, 7, 25, 17, 14, 16, 18, 19, 20, 21, 46, 52, 53, 47, 48, 54, 55, 254, 50, 51, 49, 38, 58, 255, 255, 255, // Nord Drum 2 Voice 2 MultiCh 8
{ 57, 56, 54, 23, 26, 25, 10, 7, 25, 17, 14, 16, 18, 19, 20, 21, 46, 52, 53, 47, 48, 54, 55, 254, 50, 51, 49, 38, 58, 255, 255, 255, // Nord Drum 2 Voice 3 MultiCh 9
{ 57, 56, 54, 23, 26, 25, 10, 7, 25, 17, 14, 16, 18, 19, 20, 21, 46, 52, 53, 47, 48, 54, 55, 254, 50, 51, 49, 38, 58, 255, 255, 255, // Nord Drum 2 Voice 4 MultiCh 10
{ 57, 56, 54, 23, 26, 25, 10, 7, 25, 17, 14, 16, 18, 19, 20, 21, 46, 52, 53, 47, 48, 54, 55, 254, 50, 51, 49, 38, 58, 255, 255, 255, // Nord Drum 2 Voice 5 MultiCh 11
{ 57, 56, 54, 23, 26, 25, 10, 7, 25, 17, 14, 16, 18, 19, 20, 21, 46, 52, 53, 47, 48, 54, 55, 254, 50, 51, 49, 38, 58, 255, 255, 255, // Nord Drum 2 Voice 6 MultiCh 12
{ 255, 255, 255, 255, 255, 255, 255, 255, 255, 255, 255, 255, 255, 255, 255, 255, 255, 255, 255, 255, 255, 255, 255, 255, 255, 255, 255, 255, 255, //not in Use
{ 255, 255, 255, 255, 255, 255, 255, 255, 255, 255, 255, 255, 255, 255, 255, 255, 255, 255, 255, 255, 255, 255, 255, 255, 255, 255, 255, 255, 255, //not in Use
}
```

This Mapping says which one of the 32 internal CCs are positioniered in the Mixer/Overview/Channelstrip-Mode

```
// 4 CC Route Mode = 1; // Re Channelstrip
const u8 CC_Map1[32] = { // CC_Map1 [Active_Strip_Set] [CC to remap to Map0]
// 1st Row Horizontal // 2nd Row Horizontal // 3rd Row Horizontal // 4th Row Horizontal
{ 1, 2, 3, 4, 5, 6, 7, 8, 9, 10, 11, 12, 13, 14, 15, 16, 17, 18, 19, 20, 21, 22, 23, 24, 25, 26, 27, 28, 29, 30, 31, 32, // Channel-Strip-Set1 (Filter)
{ 8, 9, 10, 11, 12, 13, 14, 15, 16, 17, 18, 19, 20, 21, 22, 23, 24, 25, 26, 27, 28, 29, 30, 31, 32, 3, 4, 5, 6, 7, 8, 9, // Channel-Strip-Set2 (Filter)
{ 15, 16, 17, 18, 19, 20, 21, 22, 23, 24, 25, 26, 27, 28, 29, 30, 31, 32, 3, 4, 5, 6, 7, 8, 9, 10, 11, 12, 13, 14, 15, // Channel-Strip-Set3 (Decay)
{ 32, 32, 32, 32, 32, 32, 32, 32, 32, 32, 32, 32, 32, 32, 32, 32, 32, 32, 32, 32, 32, 32, 32, 32, 32, 32, 32, 32, 32, 32, 32, //not used
{ 32, 32, 32, 32, 32, 32, 32, 32, 32, 32, 32, 32, 32, 32, 32, 32, 32, 32, 32, 32, 32, 32, 32, 32, 32, 32, 32, 32, 32, //not used
{ 32, 32, 32, 32, 32, 32, 32, 32, 32, 32, 32, 32, 32, 32, 32, 32, 32, 32, 32, 32, 32, 32, 32, 32, 32, 32, 32, 32, 32, //not used
{ 32, 32, 32, 32, 32, 32, 32, 32, 32, 32, 32, 32, 32, 32, 32, 32, 32, 32, 32, 32, 32, 32, 32, 32, 32, 32, 32, 32, 32, //not used
{ 32, 32, 32, 32, 32, 32, 32, 32, 32, 32, 32, 32, 32, 32, 32, 32, 32, 32, 32, 32, 32, 32, 32, 32, 32, 32, 32, 32, 32, //not used
}
// CC_Map1[0-31] = shmem CC_Map1[0-31] = Synth-CC:56 = ClickLevel-CC
// to get: CC_Map0[0-7] CC_Map1[0-7] = 56CC-Nr. = ClickGain CC_Map0[8-15] CC_Map1[8-15] = 56CC-Nr. = Bal in the End: CC_Map0[0-7] CC_Map1[Active_Strip_Set][0-32] = ...CC-Nr.
// to get: CC_Map0[8-15] CC_Map1[8-15] = 15CC-Nr. = N.Filt CC_Map0[16-23] CC_Map1[16-23] = 17CC-Nr. = N.Rev For Value: beat[0].CC_Store[32]
// to get: CC_Map0[24-31] CC_Map1[24-31] = 11CC-Nr. = N.Decay CC_Map0[32-39] CC_Map1[32-39] = 17CC-Nr. = N.Rev For Value: beat[0].CC_Store[32]
// to get: CC_Map0[40-47] CC_Map1[40-47] = 255CC-Nr. = Nothing-will be filtered out! = blank out LEADING 19 beat[0-7].CC_Store[CC_Map1Active_Strip_Set][0-32] 1
}
```

there are 8 deep edit pages, and 8 overview pages.

CC Routing to Synths

MSQ_CC_LRE internal i have 8×32 CCs, they are always identical.

but with a simple input output matrix i can decide which CC it gets in real world.

each of the 8 Part can have midichannle 0-15...

So we talking about Mapping... in the moment it is made in the source code with a simple array.

To Do

alot, but since it is base on MSQ-CC-BCR! most is done, and its running solid

maybe scale min max values for CC: for example different synths have only 0-3value instead of 0-127, by different functions like WAVEFORM...) - this will be interesting when using other synths then nord drum...

Resources

Community users working on it

- **Phatline** = Programming, Documentation...

Just let a Private message on the forum to user already involved, the sourcecode is includet in the firmware .zip!!!

From:

<http://wiki.midibox.org/> - **MIDIbox**

Permanent link:

<http://wiki.midibox.org/doku.php?id=msq-cc-lre&rev=1526062989>

Last update: **2018/05/11 19:23**

