Coil Winder

REAL:



CODE, FIRMWARE

Install MIOS Studio, connect a Core-Stm32F4 via USB, and Start the STUDIO

1. Upload MIOS BOOTLOADER
2. (only needet for Virgin Machines) type following commands into the MIOS-TERMINAL:


- set lcd_type GLCD_SSD1306_ROTATED
- set lcd_num_x 2
- set lcd_num_y 1
- set lcd_width 128
- set lcd_height 64
- store

3. Unzip the Firmware, and Upload the project.hex
4. Unconnect USB & Connect the USB again — finished.

5. If the Machine is not detected by mios studio, and you already checked the usb-connections, the device or the code is broken, for that you may search for “Bootload Switch”, please set it to “bLOAD”, now you can upload new & unbroken codes, dont forget to set it to “normal” back again - after upload new code - else the APP will not boot…

BUILD

Shemata



Community users working on it

- **Phatline** = Programming, Documentation, Hardware-Prototype, Testing, Winding

Getting Involved ?

Just let a Private message on the forum to user already involved

From:
https://www.midibox.org/dokuwiki/ - **MIDIbox**

Permanent link:
https://www.midibox.org/dokuwiki/doku.php?id=coilwinder&rev=1680466043

Last update: **2023/04/02 20:07**